

USER MANUAL

WC-COA-PRO

COALESCE PROFESSIONAL (PRO)

24/7 TECHNICAL SUPPORT AT 1.877.877.2269 OR VISIT BLACKBOX.COM



TABLE OF CONTENTS

1. SPECIFICATIONS.....	4
2. THE COALESCE PRO APP.....	6
2.1 What is Coalesce Pro?	6
2.2 Networking	6
2.3 Updates.....	6
3. GETTING STARTED	7
3.1 Meeting ID Screen	7
3.2 Status Bar Overview.....	7
4. CONNECTING ATTENDEES	9
4.1 Connect Using the Windows Application	9
4.2 Connect Using a Web Browser.....	11
4.2.1 Installing the Coalesce Pro Extension	11
4.2.2 Connecting Using the Web Client	12
4.3 Connect Using the Android Application.....	13
4.4 Connect Using the iOS Application.....	14
4.5 Connect iOS Devices Using AirPlay.....	16
4.6 Connect MacOS Using AirPlay.....	17
4.7 Minimum Requirements of Connecting Devices.....	18
5. MANAGING ATTENDEES	19
5.1 Re-ordering Attendees and Changing View	19
5.2 Adding and Removing Attendees	19
5.3 Make an Attendee Full Screen (Active Display).....	19
5.4 Take Control of a PC	20
5.5 Active Display Menu Options	21
5.6 Add a Whiteboard.....	21
6. WINDOWS APPLICATION	22
6.1 Windows Application Menu	22
6.2 Become the Active Display.....	22
6.3 View the Active Display.....	22
6.4 Pause Screen Sharing.....	23
6.5 Share Audio and Video	23
6.6 Share Media.....	23
6.7 Windows Application Settings	23
6.7.1 General Settings.....	24
6.7.2 Audio Settings	24
6.7.3 Proxy Settings	25



TABLE OF CONTENTS

7. WEB CLIENT	26
7.1 Web Client Menu	26
7.2 Become the Active Display	26
7.3 View the Active Display	26
7.4 Pause Screen Sharing	27
7.5 Share Attendee's Mic/Webcam	27
7.6 Share Media	28
8. ANDROID APPLICATION	29
8.1 Android Application Menu	29
8.2 Share Your Screen	30
8.3 Become the Active Display	30
8.4 View the Active Display	31
8.5 Share Audio/Webcam	31
8.6 Upload a File	32
9. IOS APPLICATION	33
9.1 iOS Application Menu	33
9.2 Share Your Screen	33
9.3 Become the Active Display	34
9.4 View the Active Display	35
9.5 Share Audio/Webcam	35
9.6 Upload a File	35
10. COALESCE PRO SETTINGS	36
10.1 About Tab	36
10.2 Audio Settings	37
10.3 Video Settings	37
10.4 AirPlay Tab	38
10.5 Security Tab	38
10.6 Access Point Tab	39
APPENDIX A. SUPPORT	40
A.1 Contacting Technical Support	40
A.2 Shipping and Packaging	40
APPENDIX B. DISCLAIMER/TRADEMARKS	41
B.1 Disclaimer	41
B.2 Trademarks Used in this Manual	41

CHAPTER 1: SPECIFICATIONS

TABLE 1-1. COALESCE PRO HARDWARE SPECIFICATIONS

Hardware	
Type	Android® Based SBC
Dimensions	1.18"H x 4.72"W x 4.72"D (3 x 12 x 12 cm)
Weight	0.40 lb. (0.18 kg)
Mounting Options	Console tabletop
Connectors	(1) HDMI, (1) Optical Audio, (1) RJ-45 Ethernet (10/100/1000), (1) USB 2.0, (1) USB 3.0, (1) USB-C, (1) Micro SD (1) 5-VDC power connector
Power	
Input	5 VDC, 3 A
System	
Processor	Rockchip® RK399-6 Cores 64-bit (Dual Core A72 + Quad Core A53)
Graphics Processor	Mali-T864
Internal Storage	2 GB DDR3 RAM, 16 GB Flash Storage
Wireless*	Dual Band 802.11 a/b/g/n AC2.0
Video Output	HDMI output with Audio
Streaming Video Support	HD (1920 x 1080), HD SD (1280 x 720)
Audio Output	SPDIF Digital Optical Audio
I/O	(1) USB 2.0, (1) USB 3.0, (1) USB-C, (1) Micro SD, IR
Operating System	Android 6.0 Marshmallow
Coalesce Software Pre-installed	Includes Android version of Coalesce server software built for wireless sharing.
Security Specifications	
Network Interface Cards	(1) Ethernet NIC and (1) wireless NIC
Network Settings	Accessed via Coalesce configuration panel and an (optional) admin pin; Settings include DHCP or fixed address, DNS server, SSID Name (for wireless)
Network Modes	Wireless Access Point, Ethernet Network Deployment, Dual-Network, Wireless Client
Encryption	2048-bit length encryption key, TLS/DTLS, HTTPS
Software Security and Access Options	Disable/enable local configuration, open access, pin lock, screen key

*For indoor use only.



CHAPTER 1: SPECIFICATIONS

TABLE 1-2. COALESCE PRO FEATURE SPECIFICATIONS

Client OS	
PC Application	Windows® 10, Windows 8, Windows 7 (limited support)
Chrome® Web Client	Google Chrome version 55+ - Windows - Mac® - Ubuntu®, Fedora® - ChromeOS®
AirPlay®	iOS® 9, 10 MacOS® 10.10, 10.11, 10.12
Android Application	Android 5 and above
iOS Application	iOS 10 64-bit device
Connectivity	Integrated wireless access point (can be enabled or disabled); Connect to a network using Ethernet and/or Wi-Fi; Connect to a network with DHCP or Static IP; Unique meeting ID generated on launch of new meeting; Optional PIN for added security when connected to Internet
Receiver Interface	Connect up to 8 participant's screens; Touch display support (or control via connected mouse/keyboard); Make any connected participant the Active Display; Drag & move client displays at receiver/display; Desktop control of full-screen client PC's (Active Display) from the receiver/display; Whiteboard/Annotation tools
Client Interface	
Windows Application: <ul style="list-style-type: none"> • Share your desktop • Choose to be the Active Display • Pause sharing • In-room and remote meeting access 	Chrome Web Client: <ul style="list-style-type: none"> • Share your desktop/selected application • Choose to be the Active Display • Pause sharing • In-room and remote meeting access
IOS Application: <ul style="list-style-type: none"> • Share a web page, image or video • Choose to be the Active Display • In-room and remote meeting access 	Android Application: <ul style="list-style-type: none"> • Share your device screen • Choose to be the Active Display • In-room and remote meeting access
AirPlay: <ul style="list-style-type: none"> • Connect via same subnet or Access Point • Share your screen • Use meeting ID to ensure secure connection 	

CHAPTER 2: THE COALESCE PRO APP

2.1 WHAT IS COALESCE PRO?

Coalesce Professional (Pro) is an embedded wireless presentation solution that lets 8 in-room and remote meeting attendees stream content from their device to a large format display.

To connect more than 8 attendees or to share audio and video, you'll need Coalesce Enterprise. For more information, contact Black Box Technical Support at 877-877-2269 or info@blackbox.com.

2.2 NETWORKING

Before using Coalesce Pro, make sure that your network device is connected to a wired or wireless network. Guidance on how to do this can be found in your network device's user guide.

2.3 UPDATES

Updates will appear as a prompt within Coalesce Pro within a few minutes of being launched.



CHAPTER 3: GETTING STARTED

3.1 MEETING ID SCREEN

When the Coalesce Professional (Pro) application has launched, the screen shown next will appear.




FIGURE 3-1. MEETING ID SCREEN

This screen contains the status bar at the top, the Meeting ID to join the meeting and instructions on how to connect devices on the left and right middle sides of the screen. For more information on how to connect devices, see Chapter 4.

3.2 STATUS BAR OVERVIEW

The status bar menu is at the top of the Coalesce Pro display and contains the meeting menu and a group of status icons to the right.



FIGURE 3-2. STATUS BAR

Access the meeting menu by tapping or clicking on the Black Box Double Diamond icon in the left corner, revealing the options below.







FIGURE 3-3. MEETING OPTIONS

Use these options to start a new meeting, restart the device and view and change basic settings.

Click or tap on the Meeting ID in the top left corner at any time to view the Coalesce Pro Meeting ID screen. To close this screen, click anywhere on the splash screen. The status icons are on the right side of the status bar.

CHAPTER 3: GETTING STARTED

TABLE 3-1. STATUS ICONS

SYMBOL	DESCRIPTION
 	Cloud services (internet) connected/disconnected*
	Attendees (number of connected attendees shown to right)

*Coalesce Professional (Pro) has cloud connectivity for screen sharing only.



CHAPTER 4: CONNECTING ATTENDEES

Attendees can join a meeting by using the following applications.

TABLE 4-1. CONNECTION METHODS

PLATFORM*	CONNECTION METHOD (RECOMMENDED IN BOLD)
Windows®	Coalesce Pro Windows Application (Section 4.1), Coalesce Standalone Client (Does not require Administrator rights to install) Coalesce web client (Section 4.2)
Mac OS®	Coalesce Pro web client (Section 4.2), AirPlay (Section 4.6)
Linux®	Coalesce Pro web client (Section 4.2)
Chromebook®	Coalesce Pro web client (Section 4.2)
iOS®	Coalesce Pro iOS application, (Section 4.4), AirPlay (Section 4.5)
Android®	Coalesce Pro Android application (Section 4.3)

*See section 4.7 for minimum system requirements.

NOTE: Attendees must be connected to the same local network as the Coalesce Professional (Pro) unit or be connected to an Access Point to use AirPlay.

4.1 CONNECT USING THE WINDOWS APPLICATION

Go to <http://www.joincoalesce.com/> to download the Windows application and follow the on-screen instructions to install on the PC. Once installed, double-click the Coalesce Pro icon to launch the application.



FIGURE 4-1. COALESCE PRO ICON

CHAPTER 4: CONNECTING ATTENDEES

When Coalesce Professional (Pro) opens, enter Attendee Name and the Meeting ID. You do not need to enter a PIN when connecting to a Coalesce Pro meeting.




FIGURE 4-2. LOGIN SCREEN

See Chapter 6 for more information on the Windows application.

CHAPTER 4: CONNECTING ATTENDEES

4.2 CONNECT USING A WEB BROWSER

If using Windows, Mac, Linux or Chromebook, attendees can connect using the Coalesce Professional (Pro) Web Client in Google Chrome.

Chrome can be downloaded from <http://www.google.com/chrome>.

Open Chrome and navigate to <http://www.joincoalesce.com>—attendees will see the next page.




FIGURE 4-3. LOGIN SCREEN IN CHROME WEB BROWSER INTERFACE

The Coalesce Pro Extension must be installed from the Chrome® web store to share the screen. You will be prompted to do this the first time you go to www.joincoalesce.com.

4.2.1 INSTALLING THE COALESCE PRO EXTENSION

To install the extension, click on the “get our extension” link and follow the prompts on-screen to add the extension.




FIGURE 4-4. GET OUR EXTENSION LINK

CHAPTER 4: CONNECTING ATTENDEES

4.2.2 CONNECTING USING THE WEB CLIENT




FIGURE 4-5. JOIN A MEETING SCREEN

Enter the Attendee's Name and Meeting ID. You do not need a PIN when connecting to a Coalesce Professional (Pro) meeting. Click "Join Now" when ready to connect.

Next, a prompt will appear asking what the attendee wishes to share—either the entire desktop or a specific window. Select an option, then click on "Share" to connect to the Coalesce Pro meeting.




FIGURE 4-6. CLICK SHARE TO CONNECT TO THE MEETING

When connected using the web client, attendees must keep the Chrome® browser window open to stay connected to the meeting. See Chapter 7 for more information on the Web Client.

CHAPTER 4: CONNECTING ATTENDEES

4.3 CONNECT USING THE ANDROID APPLICATION

Download the Android Application from the Google Play Store—search “Coalesce MPE.”




FIGURE 4-7. ANDROID APP

Once installed, tap the Coalesce MPE icon to open the app.



FIGURE 4-8. COALESCE PRO ICON

When the app launches, enter the criteria to join the meeting—Name, Meeting ID and PIN (if required).

CHAPTER 4: CONNECTING ATTENDEES




FIGURE 4-9. ANDROID JOIN MEETING SCREEN

See Chapter 8 for more information on the Android application.

4.4 CONNECT USING THE IOS APPLICATION

Download the iOS Application from the Apple App Store—search “Coalesce MPE.”




FIGURE 4-10. IOS APP

CHAPTER 4: CONNECTING ATTENDEES

Once installed, tap the Coalesce MPE icon to open the app.




FIGURE 4-11. COALESCE PRO ICON

When the app launches, enter the criteria to join the meeting—Name, Meeting ID and PIN (if required).




FIGURE 4-12. IOS JOIN MEETING SCREEN

Please see Chapter 8 for more information on the iOS application.

CHAPTER 4: CONNECTING ATTENDEES

4.5 CONNECT IOS DEVICES USING AIRPLAY

Make sure the iOS device is on the same network as Coalesce Pro.

Swipe up from the bottom of the screen on the iOS device to reveal the Control Center.




FIGURE 4-13. CONTROL CENTER

Select the applicable AirPlay name (you can view/change this in the Coalesce Professional [MPE] settings). An AirPlay password is required—this will be the Meeting ID.




FIGURE 4-14. SELECT AIRPLAY NAME FOR IOS

After tapping ok, the screen of the iOS device will appear on the Coalesce Pro display.

CHAPTER 4: CONNECTING ATTENDEES

4.6 CONNECT MACOS USING AIRPLAY

Mac computers can currently join using the Web Client (see Section 4.2) or by using AirPlay.

To mirror the screen using AirPlay, make sure the Mac is connected to the same network as Coalesce Professional (Pro).

When connected to a valid network with AirPlay, the AirPlay icon will be shown in the top right of the MacOS Menu Bar. Click this to see a list of available AirPlay receivers on the local network. Select the applicable AirPlay name from the drop-down list (you can view/change this in the Coalesce Pro settings).




FIGURE 4-15. LIST OF AIRPLAY NAMES FOR MAC

AirPlay will prompt for a password (this will be the Meeting ID); enter this and the Mac screen will be mirrored to the display.




FIGURE 4-16. ENTER AIRPLAY DEVICE PASSWORD

CHAPTER 4: CONNECTING ATTENDEES

4.7 MINIMUM REQUIREMENTS OF CONNECTING DEVICES

TABLE 4-2. CONNECTING DEVICES REQUIREMENTS

APPLICATION	MINIMUM REQUIREMENTS
Windows Application	Windows 10, Windows 8, Windows 7 (limited support); Minimum processor & graphics requirement: 3rd Generation Intel® Processor with Intel® HD Graphics 4000 or Intel® HD Graphics 2500 (with latest drivers)
Chrome Web client	Google Chrome® version 55+ <ul style="list-style-type: none"> ♦ Windows ♦ Mac ♦ Ubuntu®, Fedora® ♦ Chrome OS
AirPlay	iOS 9, 10; MacOS 10.10, 10.11, 10.12
Android Application	Android 5 and above
iOS Application	iOS 10; 64-bit device



CHAPTER 5: MANAGING ATTENDEES

5.1 RE-ORDERING ATTENDEES AND CHANGING VIEW

Attendees will appear in the Coalesce Professional (Pro) view when connected, as seen below. Up to a maximum of 8 attendees can be connected at once.




FIGURE 5-1. COALESCE PRO VIEW

You can alter this view by using the slider at the bottom of the screen. You can change from having 1 device on screen to a arrangement of up to 8 screens.



FIGURE 5-2. SLIDER BAR

5.2 ADDING AND REMOVING ATTENDEES

Attendees can join at any time during a session. If joining after a session has started, the Meeting ID will be visible in the top left corner of the Coalesce Pro display. Tapping on this will open the Coalesce Pro Meeting ID screen with the Meeting ID in a larger format. If the maximum amount of attendees are already connected, attendees can easily be removed by dragging an attendee's display to the trash bin. If an attendee wants to disconnect he can select to "Leave Coalesce Pro" in the app, or disconnect from Airplay or Miracast®.

5.3 MAKE AN ATTENDEE FULL SCREEN (ACTIVE DISPLAY)

To select an attendee as the Active Display, double tap that attendee in the Coalesce Pro view; this display will then become full screen. This screen is now the "Active Display."

Attendee's displays can be easily swapped between by using the Sidebar—expand the Sidebar by pulling the tab from the right side of the screen. Drag and drop the desired screen to change the Active Display.

CHAPTER 5: MANAGING ATTENDEES




FIGURE 5-3. DRAG AND DROP TO CHANGE THE ACTIVE DISPLAY

Attendees will also be able to set themselves as the Active Display from within the Windows application (see Section 6.2) and web client (see Section 7.2).

5.4 TAKE CONTROL OF A PC

When a Windows PC using the Coalesce Professional (Pro) Windows application is set as the Active Display, Coalesce Pro has full mouse control of that PC from the display.

CHAPTER 5: MANAGING ATTENDEES

5.5 ACTIVE DISPLAY MENU OPTIONS




FIGURE 5-4. ACTIVE DISPLAY MENU OPTIONS

TABLE 5-1. ACTIVE DISPLAY MENU OPTIONS

OPTION	DESCRIPTION
Back to Coalesce Pro view	Select this option to return to the Coalesce Professional (Pro) view of all connected devices.
Annotation tool	Used to annotate over the current display. Click or tap to cycle through colors.
Mouse control	Take mouse control of a PC connected using the Coalesce Pro Windows Application.
Clear annotations	Delete all annotations from the current screen.
Show/hide webcam	Show or hide the on-screen webcam.
Capture screen	Capture a screenshot of the current screen and send to connected attendees (Windows application/Web client only).
Volume control	Control the volume of any audio output connected to Coalesce.

5.6 ADD A WHITEBOARD

If required, you can add a whiteboard to the meeting view by dragging and dropping the “Add whiteboard” window from the sidebar.




FIGURE 5-5. ADD WHITEBOARD

CHAPTER 6: WINDOWS APPLICATION

6.1 WINDOWS APPLICATION MENU




FIGURE 6-1. WINDOWS APPLICATION MENU

6.2 BECOME THE ACTIVE DISPLAY

A device can be made the Active Display by clicking the "FULL" icon in the menu bar. This will make that attendee's device full screen on the main display and will automatically share that PC's system audio. The content will also be viewable by anyone viewing the Active Display on the Coalesce apps or web client - see Section 6.3.

When an attendee is presenting, he can take control of his PC from the main display.

6.3 VIEW THE ACTIVE DISPLAY

On meetings started on Linux and Windows Receivers, the current Active Display can be viewed by selecting the "View Active Display" icon. The screen will change with extra options, as shown next.




FIGURE 6-2. ACTIVE DISPLAY OPTIONS

CHAPTER 6: WINDOWS APPLICATION

An attendee can deselect themselves as the Active Display (stopping others from viewing the screen) by pressing the red Active Display button. Pressing the + button will expand with additional options, giving quick access to pasue screen, turn on/off outgoing audio, start/stop sharing webcam or to share a file.

Annotations can be made using the Annotation tool. These will be visible on the main display and to all other attendees viewing the Active Display.

6.4 PAUSE SCREEN SHARING

The attendee can press the “PAUSE” button at any time, allowing them to use other applications without them being shared to the main display. Click again to resume sharing.

6.5 SHARE AUDIO AND VIDEO

System audio is automatically shared for an attendee connecting via the Coalesce Windows application when they are the Active Display. The Mic on the toolbar can be enabled, which will disable system audio. Specific settings for audio inputs and outputs can be controlled from within the Coalesce Windows application fo the attendee before they join the meeting (see Section 6.7).

6.6 SHARE MEDIA

Files can be uplaoded directly to Coalesce from client devices using the media player functionality in Coalesce Windows and Web Client.

Files can be download from the Coalesce to your computer via the media player.

6.7 WINDOWS APPLICATION SETTINGS

The Coalesce settings are accessible from the menu in the top left.




FIGURE 6-3. SETTINGS

CHAPTER 6: WINDOWS APPLICATION

6.7.1 GENERAL SETTINGS




FIGURE 6-4. GENERAL SETTINGS TAB

Share my screen — Set whether the screen is shared when connecting to a meeting.

6.7.2 AUDIO SETTINGS




FIGURE 6-5. AUDIO TAB

Audio Input — Set the input source for the audio when connected to the meeting.

Audio Output — Set the output for the audio when connected to the meeting.

Mute audio at source — Automatically mute system audio from your PC once you connect.

CHAPTER 6: WINDOWS APPLICATION

6.7.3 PROXY SETTINGS

Configure Coalesce to work through a proxy.-




FIGURE 6-6. PROXY TAB

NOTE: To connect via the Web Client, see Section 4.2.

7.1 WEB CLIENT MENU




FIGURE 7-1. WEB CLIENT MENU

7.2 BECOME THE ACTIVE DISPLAY

A device can be made the Active Display by clicking the “Select/De-select as Active Display” icon in the menu bar. This will make that attendee’s device full screen on the main display. This will also share the content to anyone viewing the active display on the Coalesce apps or Web client. See Section 7.3.

NOTE: Mouse control of the Active Display is not available when using the web client.

7.3 VIEW THE ACTIVE DISPLAY

On meetings started on Coalesce Linux and Windows Receivers, the Active Display can be viewed by selecting the “View Active Display” icon in the toolbar. This will allow the attendee connected via the Web Client to view the current Active Display with Chrome.

When Active Display is selected, additional options appear allowing the user to annotate, select and erase annotations from the content. Annotations will be visible on the main display and to all other attendees viewing the Active Display.




FIGURE 7-2. VIEW THE ACTIVE DISPLAY

An attendee can de-select themselves as the Active Display (stopping others from viewing the screen) by clicking the red Active Display button on the Coalesce toolbar.

7.4 PAUSE SCREEN SHARING

The attendee can press the “pause screen sharing” button at any time, allowing them to use other applications without sharing them to the main display. Click again to resume sharing.

7.5 SHARE ATTENDEE’S MIC/WEBCAM

The attendee can share their PC’s microphone and webcam by enabling the corresponding button on the Coalesce Web Client toolbar. For best results, if there are multiple in-room attendees, do not activate more than one attendee’s microphone per room, or enable a microphone connected directly to the Coalesce receiver.



FIGURE 7-3. SHARE MIC/WEBCAM

NOTE: To send system audio, you must be using the Coalesce Windows application.

CHAPTER 7: WEB CLIENT

7.6 SHARE MEDIA

Files can be uploaded directly to Coalesce from client devices using the media player functionality in Coalesce Windows and Web Client. Files can be download from the Coalesce to your computer via the media player.



NOTE: To connect with the Android Application, see Section 4.3.

8.1 ANDROID APPLICATION MENU (AFTER JOINING THE MEETING)




FIGURE 8-1. ANDROID APPLICATION MENU

CHAPTER 8: ANDROID APPLICATION

8.2 SHARE YOUR SCREEN

Tap the “Screen share” button on the tool bar to pause or resume screen sharing. The button will indicate whether the screen is being shared—see below.




FIGURE 8-2. SCREEN SHARING BUTTON




FIGURE 8-3. NOT SHARING SCREEN BUTTON

8.3 BECOME THE ACTIVE DISPLAY

If the attendee on the Android device wishes to become the Active Display, he can do this by tapping the “Active Display” button.




FIGURE 8-4. ACTIVE DISPLAY BUTTON

This will make that attendee’s device full screen on the main display, which will also share the content to anyone viewing the active display on the Windows Application, Web Client or iOS and Android applications.

8.4 VIEW THE ACTIVE DISPLAY

The Active Display can be viewed once an attendee becomes the Active Display. This will automatically be shared to the attendee connected using the Coalesce Android application.




FIGURE 8-5.

8.5 SHARE AUDIO/WEBCAM

From outside the room, microphone, webcam and speakers can be enabled using the buttons on the toolbar.



FIGURE 8-6. MICROPHONE, CAMERA AND AUDIO OFF




FIGURE 8-7. MICROPHONE, CAMERA AND AUDIO ENABLED

CHAPTER 8: ANDROID APPLICATION

8.6 UPLOAD A FILE

Files can be uploaded using the button at the top right of the app. If a compatible file format, this will be able to be played from the Coalesce Media Player, or if not, attendees using the Windows/web client can download the file to their PC to open in the correct program.



NOTE: To connect with the iOS application, see Section 4.4.

9.1 IOS APPLICATION MENU




FIGURE 9-1. IOS APPLICATION MENU

9.2 SCREEN SHARING

Tap the "Screen share" button on the tool bar to pause or resume screen sharing. The button will indicate whether the screen is being shared.




FIGURE 9-2. NOT SHARING THE SCREEN

CHAPTER 9: IOS APPLICATION




FIGURE 9-3. SHARING THE SCREEN

NOTE: Currently only a web browser, image or video can be shared using the iOS application.

9.3 BECOME THE ACTIVE DISPLAY

If the attendee on the iOS device wishes to become the Active Display, he can do this by tapping the “Active Display” button.




FIGURE 9-4. ACTIVE DISPLAY BUTTON

This will make that attendee’s device full screen on the main display, which will also share the content to anyone viewing the active display on the Windows® Application, Web Client or iOS and Android applications.

CHAPTER 9: IOS APPLICATION

9.4 VIEW THE ACTIVE DISPLAY

Once an attendee becomes the active display, this will automatically be shared to the attendee connected using the Coalesce iOS application.

9.5 SHARE AUDIO/WEBCAM

From outside the room, microphone, webcam and speakers can be enabled using the buttons on the toolbar.



FIGURE 9-5. MICROPHONE, CAMERA AND AUDIO OFF



FIGURE 9-6. MICROPHONE, CAMERA AND AUDIO ENABLED

9.6 UPLOAD A FILE

A file can be uploaded using the button at the top right of the app. If a compatible file format, this will be able to be played from the Coalesce media player, or if not, attendees using the Windows/web client can download the file to their PC to open in the correct program.

CHAPTER 10: COALESCE PRO SETTINGS

To access the settings menu, click or tap on the top left corner of the Coalesce Professional (Pro) home screen. The drop-down menu will appear—tap or click on Settings.




FIGURE 10-1. DROP-DOWN MENU

The settings menu is arranged into different tabs:

- ♦ About: To view general information on the Coalesce, including Coalesce version, serial number and network name.
- ♦ General: To modify features, such as cloud connectivity, file sharing, AirPlay receiver settings or to set a PIN for extra security.
- ♦ Audio: Change audio inputs and outputs.
- ♦ Video: Change video input
- ♦ Proxy: Configure the proxy setting for the Coalesce app
- ♦ Security: Remove or change the settings PIN (if activated)

10.1 ABOUT TAB

The About tab in the settings contains information about Coalesce Pro.




FIGURE 10-2. ABOUT TAB OPENED


TABLE 10-1. ABOUT TAB SETTINGS

ITEM	DESCRIPTION
Coalesce Pro version	The version of Coalesce Pro currently running. The Coalesce Pro unit will check for updates automatically when connected to the Internet; install these when prompted.
S/N	The Coalesce Pro Serial Number
Network name	The network name that will show on devices connecting by Airplay

CHAPTER 10: COALESCE PRO SETTINGS

10.2 AUDIO SETTINGS

Select the devices to be used during meetings as your audio input and output.




The screenshot shows a dark-themed settings panel. At the top, the text "Audio Input" is displayed. Below it is a white dropdown menu with the text "Microphone (Realtek High Definition Audio)" and a downward arrow. Further down, the text "Audio Output" is displayed. Below it is another white dropdown menu with the text "Speakers (Realtek High Definition Audio)" and a downward arrow.

FIGURE 10-3. AUDIO SETTINGS

10.3 VIDEO SETTINGS

Choose from the drop-down list of available camera sources.



The screenshot shows a dark-themed settings panel. At the top, the text "Select video output" is displayed. Below it is a white dropdown menu with the text "Lenovo EasyCamera" and a downward arrow.

FIGURE 10-4. VIDEO SETTINGS

CHAPTER 10: COALESCE PRO SETTINGS

10.4 AIRPLAY TAB

The AirPlay tab of the Settings screen allows for the AirPlay name to be changed—type the new name into the text box and tap “Apply” to confirm.




FIGURE 10-5. CHANGE AIRPLAY NAME

10.5 SECURITY TAB

The Security tab of the Settings screen enables you to remove or change the Unlock Code—click on the appropriate button.




FIGURE 10-6. REMOVE OR CHANGE THE UNLOCK CODE

CHAPTER 10: COALESCE PRO SETTINGS

If you clicked on the Change Unlock Code button, the following screen appears. Enter a 4-digit unlock code.




FIGURE 10-7. ENTER THE UNLOCK CODE

10.6 ACCESS POINT TAB

The Access Point tab of the Settings screen allows you to add an access point—type the SSID and password into the text box and tap “Apply” to confirm.




FIGURE 10-8. ADD AN ACCESS POINT SCREEN

APPENDIX A: SUPPORT

A.1 CONTACTING TECHNICAL SUPPORT

If you determine that your Coalesce Pro is malfunctioning, do not attempt to alter or repair the unit. It contains no user-serviceable parts. Contact Black Box Technical Support at 877-877-2269 or info@blackbox.com.

Before you do, make a record of the history of the problem. We will be able to provide more efficient and accurate assistance if you have a complete description, including:

- ♦ the nature and duration of the problem.
- ♦ when the problem occurs.
- ♦ the components involved in the problem.
- ♦ any particular application that, when used, appears to create the problem or make it worse.

A.2 SHIPPING AND PACKAGING

If you need to transport or ship your Coalesce Pro:

- ♦ Package it carefully. We recommend that you use the original container.
- ♦ If you are returning the unit, make sure you include everything you received with it. Before you ship for return or repair, contact Black Box to get a Return Authorization (RA) number.



APPENDIX B: DISCLAIMER/TRADEMARKS

B.1 DISCLAIMER

Black Box Corporation shall not be liable for damages of any kind, including, but not limited to, punitive, consequential or cost of cover damages, resulting from any errors in the product information or specifications set forth in this document and Black Box Corporation may revise this document at any time without notice.

B.2 TRADEMARKS USED IN THIS MANUAL

Black Box and the Black Box logo type and mark are registered trademarks of Black Box Corporation.

Any other trademarks mentioned in this manual are acknowledged to be the property of the trademark owners.

NOTES

NEED HELP?
LEAVE THE TECH TO US
**LIVE 24/7
TECHNICAL
SUPPORT**
1.877.877.2269

Lined area for notes.



NOTES

NEED HELP?
LEAVE THE TECH TO US

LIVE 24/7
TECHNICAL
SUPPORT
1.877.877.2269

Horizontal lines for notes.

**NEED HELP?
LEAVE THE TECH TO US**

**LIVE 24/7
TECHNICAL
SUPPORT**

1.877.877.2269



© COPYRIGHT 2018 BLACK BOX CORPORATION. ALL RIGHTS RESERVED.
WC-COA-PRO_USER_REV1A.PDF